


2-in-1 Infant Swing

Model: #1821


INFANT CONFIGURATION:

Unfold toddler seat and tee bar upright 90°. Insert child into seat and secure nylon safety straps using clips found on the top rear of seat and ends of both safety straps. Adjust straps as needed to secure child into swing.



TODDLER CONFIGURATION:

Fold toddler seat and tee bar down 90°. Make sure nylon safety straps are secured under the toddler seat. Insert child into swing.





ATTACHMENT INSTRUCTIONS:

INSERT QUICK LINK INTO QUICK LINK.

TIGHTEN QUICK LINK.

REPEAT PROCESS FOR SECOND QUICK LINK ATTACHMENT.



Limited Warranty

This Limited Warranty by Backyard Discovery applies to products manufactured under the Backyard Discovery brand or its other brands including but not limited to Backyard Botanical, Adventure Playsets, and Leisure Time Products.

Backyard Discovery warrants that this product is free from defect in materials and workmanship for a period of one (1) year from the original date of purchase. This one (1) year warranty covers all parts including wood, hardware, and accessories. Refer to the schedule below for charges associated with replacement of parts under this Limited Warranty. In addition, Backyard Discovery will replace any parts within the first 30 days from date of purchase found to be missing from or damaged in the original packaging.

*This warranty applies to the original owner and registrant and is **non-transferable**.*

Pro Rated Part Replacement Schedule

<u>Product Age</u>	<u>Customer Pays</u>
All Parts	
0-30 days from date of purchase	\$0 and free shipping
31 days to 1 year	\$0 + S&H

Save this assembly manual for future reference in the event that you need to order replacement parts.

Manufacturer: Backyard Discovery
3001 North Rouse
Pittsburg, KS 66762
1-800-856-4445